



SECURESPOT

SOLAR BOLLARD

INSTRUCTIONS &
MAINTENANCE GUIDE

SUPPLY & INSTALLATION OF CAR PARK BOLLARDS

What's in the box?



- 1: Battery Wall Charger
- 2: Remote Controls (x2)
- 3: Keys (x2)

How do I use my bollard?



Point your remote control in the direction of your bollard and press the left "lock" button to raise your bollard into the upright position

Point your remote control in the direction of your bollard and press the right "unlock" button to lower your bollard to park

Your remote control can work from up to a distance of 15metres away

Remember to slide the cover over the buttons to protect them from accidentally being pushed

If indicator light is not coming on; you may need to change the remote control batteries (unscrew remote control and replace 1 x A27 battery)

How do I charge the battery?



To remove your bollard battery for charging, you must follow these simple steps (as pictured):

- Step 1: Raise the bollard in the upright position
- Step 2: Use your key to unlock the back of the unit
- Step 3: Remove lid from bollard and set aside
- Step 4: Unplug the battery from the bollard's cable
- Step 5: Plug the battery into your Wall Charger and plug into a powerpoint. We recommend that you charge your battery for no more than 6-8 hours. For safety, do not leave the battery charging unattended overnight. Once charged, follow the above steps in reverse.

HOW TO GET THE MOST OUT OF YOUR BOLLARD

1) REVERSE IN. We recommend that you reverse in to your car space as you are less likely to come into contact with the bollard at any time. If you drive in forwards to your car space however, the risk of hitting your bollard is greater and over time, may affect the operation of your bollard. Warranty does not cover damage to the bollard.

2) CLOSE THE REMOTE CONTROL SLIDER WHEN NOT IN USE. Each time you push the button for operation, ensure you push up the slider. This will cover the buttons and prevent you from accidentally pressing the buttons, which may activate and cause damage to your bollard.

3) EMERGENCY OPERATION. If you need to manually operate your bollard (i.e. if your battery runs out); pull up on the bollard **SLOWLY** to the minimum height where you can remove the battery. You will be able to push down the bollard.

4) CHARGE YOUR BATTERY. We recommend removing the battery from your bollard, and charge utilising the wall charger provided, every 12-18 months depending on usage.

5) WIPE SOLAR PANEL. To avoid a build-up of debris that can lead to corrosion, we recommend giving the solar panel a quick wipe down with a every couple of weeks.



Additional Bollard Batteries, Remote Controls, Remote Control Batteries and Wall Chargers may be purchased; please contact us for details or you may purchase through our website. We also provide after sales support*

If you need any help or have any questions, please contact us.

info@seurespot.com.au | www.seurespot.com.au | 1300 583 231 |

*Any onsite support may incur a call out fee.