



PADLOCK INSTRUCTIONS

To use:

1. Insert key, then pull up the shackle.
2. To lock, press the shackle back down into the body of the lock.

Always keep your keys in a safe place away from others.

Cleaning:

Over time, dust, particles and chemicals in the air can create friction inside the locks' components hindering the performance of the lock.

We recommended cleaning and lubrication every 3-6 months to keep your lock operating like new. If you are using your lock outdoors, or in a dusty/corrosive environment, you should follow this process every 3 months.

1. To clean the lock, use pressurized air to blow all dust out of the keyway and shackle openings.
2. Lubricate your lock using an all-purpose oil or lubrication spray, but **AVOID** using dry graphite, or a silicone lubricant as these can cause damage to your lock.
3. Apply lubricant sparingly. All you will need is a very light spray(aerosol), or a few drops(oil). Lubricate both the keyway and the shackle.
4. Allow lubricant to drain into the lock. You can tap the lock on a table to help distribute the lubricant inside the lock.
5. After application, insert the key and open and close the lock several times to distribute the lubricant. Wipe excess lubricant off the lock, shackle and key using a microfiber cloth and let the lock air dry. Once dry, it's ready to use again.